





GRILL ASSEMBLY


To assemble your VidelUSA Grill, follow this guide.

GLOSSARY


- A.** Cast Stainless Steel Burners



- B.** Flavor Bars




- C.** Flame Tamer




- D.** Flame Runner



- E.** Grill Grates





Your Videll USA Grill will arrive with the Cast Stainless Steel Burners (A) & the Flame Runners (D) pre-installed. This guide is meant to walk you through the assembly of the remaining components for Videll USA Grills.

To assemble your VidellUSA Grill, follow this guide.




Fig. 1

STEP 1:

Locate the screw (**Fig. 1**) attached to the Flame Runner (D). Using a screwdriver, remove the Flame Runner. The Flame Tamers cannot be placed properly until the Flame Runners are removed.





Fig. 2


STEP 2:

Once you have removed the Flame Runner, place the Flame Tamer (C) beneath the Cast Stainless Steel Burner (A) and atop the bottom row of pegs as seen in **Fig. 2**. Once the Flame Tamer is in place, re-attach the Flame Runner with the same screw from **Fig. 1**.




STEP 3:

Repeat step 2 for each individual Flame Tamer (**C**). The end result will resemble **Fig. 3**.




STEP 4:

Once all Flame Tamers are set up, place the Flavor Bars (**B**) on the top row of pegs. (**Fig 4**) Repeat this step until all Flavor Bars are in place.



STEP 5:

Now place the Grill Grate (**E**) on the top railing seen in **Fig 5**. Repeat this step until all Grill Grates have been placed.



STEP 6:

The final result should match **Fig 6**. Your Grill is now fully assembled!

For additional assistance, questions or concerns please contact our support team at support@videlusa.com, or by calling (909) 460 -5579.